Protocol for E. coli Cultures Homogenization in the Bullet Blender™

The protocol described in this document is for the use of the Bullet BlenderTM for the homogenization of *Escherichia coli* (or other bacterial) cultures. This protocol does not specify a particular buffer - you may choose which is most appropriate for your downstream application (nucleic acid isolation, protein extraction, etc.).

Materials Required: E. coli, aspirator, Bullet Blender™, homogenization buffer,

pipettor, microcentrifuge tubes, and <u>0.15mm zirconium oxide</u> <u>beads (part number ZrOB015) or 0.1mm glass beads (part</u>

number GB01)

Instructions

- 1. Pour overnight bacterial culture into a microcentrifuge tube.
- **2.** Centrifuge culture to yield a cell pellet (2000g for one minute).
- **3.** Completely aspirate the supernatant liquid. Place tube on ice.
- **4.** Inspect the volume of the pellet. It should be 300µL or less in order to get efficient homogenization.
- **5.** Add an equal volume of zirconium oxide beads (0.15mm) **OR** glass beads (0.1mm) to the tube. See **NOTES** below.
- **6.** Add 0.1mL to 0.6mL buffer (2 volumes of buffer for every volume of cells).
- **7.** Snap the caps centrifuge tubes closed.
- **8.** Place tubes into the Bullet Blender™.
- 9. Set controls for SPEED 8 and TIME to 3 minutes. Press Start.
- **10.** After the run, remove tubes from the instrument.
- **11.** Visually inspect samples. If homogenization is unsatisfactory, run for another two minutes at the **SPEED 8.**
- 12. Proceed with your downstream application.

SAFETY NOTE!!!

When using a centrifuge to separate your homogenate from the debris and beads, make sure your tubes are balanced.

NOTES

Different species of bacteria and different applications will be amenable to different bead types. Cell density, cell size, and buffer composition will affect homogenization and variation of the bead selection is an easy way to empirically determine what works best. For tougher cells, we recommend using zirconium oxide beads. Increasing the speed to 10 will also help homogenize tougher cell cultures.



Scientific Instrument Services, Inc.™

1027 Old York Rd. Ringoes, NJ 08551-1039

Phone: (908)788-5550 www.sisweb.com Fax: (908) 806-6631